

### HAND DISINFECTION MACHINE

Name	ODR-1 mains version	ODR-1A battery version
Marking	<b>(€</b> ⊕	12V DC
Power supply	12V DC 3A	12V DC
Battery capacity [Ah]	-	18
Tank volume [l]	5	
Dispenser type	drop-dispenser	
Design	steel	
Dimensions (H x W x D) [mm]	1450 x 365 x 250	
Power cord length [m]	1.5	
Weight [kg]	44	49



durable, made of metal




for indoor



powder coated

#### Available colours:



grey (RAL7047)

white (RAL9003)

turquoise (RAL6027)

# The ODR-1 station is intended for touch-free hand disinfection using the dedicated disinfectant.

For easier use, the station can be accessed from both sides, and it also has wheels to make it easier to move.



Please submit all enquiries by e-mail to: marketing@omag.pl

ORDER DELIVERY TIME UP TO 3 WEEKS



By ordering this device, I accept the General Terms of Sale published at ows.omag.pl






# ROOM DISINFECTION MACHINE

Name	OMED-1
Marking	(€ ⊕
Power supply	230V AC 50Hz
Power rating	1200 W
Tank capacity	1 litre
Spraying rate	80 m/s
Max. size of disinfected rooms	360 m³
IP protection rating	IP20
Disinfectant consumption rate	up to 3 ml/m³
Dimensions (H x W x D)	420 x 235 x 330 [mm]
Power cord length	1.5 m
Weight	10 kg

- Light and functional.
- Made of stainless steel.
- Easy to use equipped with a control panel.
- Kills bacteria and viruses.
- Perfect for offices, schools and kindergartens.
- Particularly recommended for healthcare services and other public bodies.
- Does not leave smudges or wet marks safe for electronic equipment.
- Disinfection time: from 5 to 60 min (depending on the size of the room).
- Recommended disinfectant: 6% hydrogen peroxide solution.
- Warranty: 12 months.







for indoor use



kills bacteria and viruses

## The OMED-1 station is designed to disinfect enclosed areas.

The fumigator sanitises the rooms by fogging. Dry mist reaches all areas, particularly those that cannot be disinfected using conventional disinfection methods. OMED-1 has a simple panel to easily set the operating time of the station depending on the size of the room.



The room must be empty while the machine is working.

It is not allowed for any people and animals to stay in the room while it is disinfected.



Please submit all enquiries by e-mail to: marketing@omag.pl

ORDER DELIVERY TIME UP TO 3 WEEKS



By ordering this device, I accept the General Terms of Sale published at ows.omag.pl

